

# Ring Lock™

By **SAFE-T-SHADE®**

## Ring Lock® (patented) Assembly Directions

### Ring Lock® (patented):

- You will be making your shade by putting your rings from the bottom to the top. When using 1.4mm cord, space your rings 6"-8" apart. If using .9mm cord we recommend 6" spacing of the rings
- Tie cords on last ring at the bottom hem



- Place the Ring Lock® over the ring, then run the cord up through hole of Ring Lock®. Be sure to leave enough cord to run across top, through cord lock leaving a sufficient amount of operating cords available.



**We recommend the following:**

**Use of 1.4 mm cord for the Safe-T-Shade® Ring Lock® product for folds 8" or less.**